## INSTALLATION INSTRUCTIONS

## Diamondback Rubber Grips

## WARNINGS & ALERTS:

- READ AND FOLLOW ALL INSTRUCTIONS TO PROPERLY INSTALL THESE GRIPS.
- IMPROPER INSTALLATION CAN CAUSE UNSATISFACTORY AND/OR UNSAFE OPERATION.
- READ ALL THE INSTRUCTIONS CAREFULLY BEFORE INSTALLING THIS KIT ON YOUR MOTORCYCLE. USE YOUR SERVICE MANUAL AS A REFERENCE WHILE
  INSTALLING THIS KIT.



- 1. Remove existing grips from your motorcycle. Use of a rasor blade to cut the length of the old grip may ease removal.
- 2. Install the grip with smaller inside diameter directly onto the clutch side of the bar. Grips can be installed dry by using an air compressor nozzle to blow air inside the grip as you slide on the grip. The inside of the grip can also be coated with a small amount of soapy water to ease installation. Ensure the grip is fully installed and the grip is not twisted before the soapy water mix dries.
- 3. Install the grip with the larger inside diameter onto your existing throttle tube in the same manner as the clutch side.
- 4. If using soapy water to install you will need to wait at least 6-8 hours for the grips to dry and adhere to the bars properly.
- 5. If grip movement is noticed during riding after following these instructions a motorcycle specific grip glue may be used to help adhere the grip to the bar.

## LIMITED GUARANTEE

We continually inspect and try to improve our products. All parts have been inspected prior to packaging, and our guarantee is limited to replacement of defective parts. This guarantee is in lieu of all guarantees or warranties implied or expressed. Because we can not control the application of our products, the buyer assumes risks for any and all damage caused by themselves or any third party, by virtue of failure of these parts. We make no warranty as to products distributed by us, expressed or implied, including without limitation, any warranties or merchant ability and fitness for particular purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties. The manufacturer shall solely be responsible for any damage to person or property arising from design, manufacturing and testing of all products, and we accept no liability for such damages. We shall not be liable for indirect or consequential damages.

